

Fire Alarm Control Panel Operating Instructions	
Installed By: _____ _____ _____ _____ Per NFPA Standard: <input type="checkbox"/> 72, Ch 3 - Local <input type="checkbox"/> 72, Ch 4 - Auxiliary <input type="checkbox"/> 72, Ch 4 - Remote Sta. <input type="checkbox"/> 72, Ch 4 - Proprietary <input type="checkbox"/> 72, Ch 4 - Central Sta. Dated: _____	Location: _____ <hr/> <p>Normal Condition: The Power LED (green) is on. All other LEDs are off.</p> <p>Alarm Condition: The Alarm LED (red) turns on, the display shows the alarm location and zone, and the internal buzzer pulses.</p> <p style="margin-left: 20px;">To view other alarm messages: Press the ALARM review switch (down arrow). To silence audible devices: Press the Alarm Silence switch. To reset the system: Find the cause of the alarm condition, correct it, and press the Reset switch.</p> <p>Note: Each new alarm will resound the audible devices, but you cannot resound them by pressing the Alarm Silence switch a second time.</p> <p>Supervisory Condition: The Supervisory LED (yellow) turns on, the display shows the supervisory condition, location, and zone, and the internal buzzer pulses.</p> <p style="margin-left: 20px;">To view other supervisory messages: Press the SUPVR review switch (down arrow). To silence buzzer: Press Local Silence switch. To clear the system: Find the cause of supervisory condition, correct it, and press the Reset switch.</p> <p>Trouble Condition: The system Trouble LED (yellow) turns on, the display shows the trouble location and zone, and the internal buzzer pulses.</p> <p style="margin-left: 20px;">To view other trouble messages: Press the TRBLE review switch (down arrow). To silence the buzzer: Press the Local Silence switch. To clear the system: Find the cause of the trouble and correct it. The system automatically clears itself upon correction of trouble condition.</p> <p>Monitor Condition: The Monitor LED (yellow) turns on, the display shows monitor conditions, and the internal buzzer pulses during a non-fire alarm condition.</p> <p style="margin-left: 20px;">To view other monitor conditions: Press the MONTR review switch (down arrow). To clear system: The system automatically clears itself upon restoration of monitor condition.</p> <p>Fire Drill: Notify the fire department before you run the test. All audible and visual notification appliances will operate during a drill.</p> <p style="margin-left: 20px;">To drill all notification appliances: Press the Drill switch. To end the drill: Press the Drill switch a second time, or press Alarm Silence.</p> <p>Frame these instructions and mount them next to the fire alarm control panel. For additional information, See the <i>System Operations Manual</i>.</p>
For Service Contact: _____ _____ _____ _____	
Inspected By: _____ _____ _____ Date: _____	
Power Supply: Primary _____ Location _____ Fuses _____ Secondary _____ Type _____ Specs. _____	

STDOP007.CDR

Figure A-1: Fire alarm control panel operating instructions

